



Polycom Documentation

Copyright © 2021, Polycom, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc
6001 America Center Drive

San Jose, CA 95002

USA

Connecting to a Wireless Network

You can connect to a wireless network from your USB-enabled VVX phone using the Polycom® Wi-Fi wireless network adapter to access all phone services over the wireless network.

You cannot use a wireless network and Ethernet simultaneously to connect VVX phones to your network. Enabling wireless connectivity automatically disables the Ethernet port.

Add a Wireless Network

You can manually add a new wireless network on VVX phone from the **Basic** menu.

Procedure

- 1 Go to **Settings > Basic > Wi-Fi**.
- 2 Select **Add Network** to manually add a wireless network.
- 3 Enter the wireless network in SSID.
- 4 From **Security** select the network security type and other relevant security parameters along with any other wireless settings.
- 5 Save these selected settings. After saving these settings, phone will try to connect to the saved network.

Enable Wireless Network Connectivity

You can enable wireless connectivity for your USB-enabled VVX phone using the Polycom® Wi-Fi wireless network adapter.

Prerequisite

Before setting up a wireless network, make sure that you connect the VVX phone to its power adapter.

Note VVX phones do not support WEP.

Procedure

- 1 Insert the Polycom Wi-Fi wireless network adapter into the USB port of your VVX phone.
- 2 Select **Start**.
- 3 Select **Wi-Fi**, then select **On**.
- 4 Select **Yes** to reboot the phone.

After the phone reboots, Wi-Fi is enabled.

The phone scans for wireless networks and lists any that are available. If the phone does not automatically scan, select **Scan** to manually initiate a Wi-Fi network scan.

Note The administrator can configure the regulatory domain for your location and radio frequency bands on which the wireless network operates. If not configured, the phone uses the Global regulatory domain and 2.4 GHz and 5 GHz default radio bands.

Connect to a Secured Wireless Network

You can select a PSK or an enterprise-based security option to connect your VVX phone to a secured wireless network.

Procedure

- 1 Navigate to **Settings > Basic**.
- 2 Select **Wi-Fi**.
- 3 Do one of the following:
 - For a WPA(2)-PSK network, enter the **Password**.
 - For a WPA2-enterprise network, enter **User ID** and **Password**.

Note Your administrator sets the appropriate EAP method to connect to an enterprise-based network.

- 4 Select **Connect**.

The phone connects to the Wi-Fi network and displays the Wi-Fi connection status on the **Menu** and **Home** screens.

Disconnect from a Wireless Network

You can disconnect from a wireless network connection on your VVX phone.

Procedure

- 1 Navigate to **Settings > Basic**.
- 2 Select **Wi-Fi**.
- 3 Select the connected wireless network SSID from the list.
- 4 Select **Disconnect**.

Remove a Wireless Network

You can remove a saved wireless network connection on your VVX phone.

Procedure

- 1 Navigate to **Settings > Basic**.
- 2 Select **Wi-Fi**.
- 3 Select the connected wireless network SSID from the list.
- 4 Select **Forget**.